

WP-T810 Thermal Printer

9 Select error beep alarm

SW2-6	Error beep alarm
OFF	Silence
ON	Alarm

10 Select paper width

請先「關機」再進行調整DIP SWITCH，謝謝。

SW2-7	Paper width
OFF	80 mm
ON	58 mm

11 Select page print mode

SW2-8	Page print mode
OFF	Disable
ON	Enable